


# FL!KT

## THERMAL HOT BRUSH USER MANUAL



Please read the user manual carefully before use  
and keep it for future reference.

## ABOUT THE TOOL

This hot brush ensures even heat distribution, while the ergonomic handle and anti-scald nylon bristles make it easier to get natural curls. Use it to straighten and curl your hair or simply as a normal comb.

## HOW TO USE

1. Start by making sure your hair is fully dry and detangled.
2. Once you've plugged in your hot brush, press the power button until the tool switches on.
3. To select your temperature, press the +/- buttons to find your desired heat.
4. Next, divide your hair into manageable sections.
5. Select a section and glide the hot brush slowly from root to end to smooth hair.
6. Use the tool to lift hair at the roots to create volume and brush under at the ends to add shape.
7. To create loose waves, wrap or twist sections around the brush and hold for 2-3 seconds before releasing.
8. Allow hair to cool, then finish with styling products if needed.
9. Unplug, cool, and clean the brush after use.

## KEY FEATURES



### Locks in moisture

Ceramic glaze heats hair evenly from the inside out to lock in moisture and reduce frizz.



### Healthier hair

Nano Technology works to prevent bacterial growth for cleaner hair.



### Smooth finish

Seals the cuticle to smooth the hair's surface for bounce and shine.



### Easy to use

The 360 swivel cord is flexible for hassle-free styling.

## WHICH HEAT SETTING?

**90°C - 150°C**

Fine, easy-to-style hair

**150°C - 190°C**

Average-to-thick, treated hair

**190°C - 230°C**

Thick, textured hair

## IMPORTANT SAFETY GUIDELINES AND RECOMMENDATIONS FOR USING THIS PRODUCT:

1. Never leave this product unattended when it is plugged in. Always remember to unplug it immediately after use.
2. Close supervision is necessary if the product is being used by children or individuals with certain disabilities.
3. Ensure that all the air openings remain free and unobstructed while using the product.
4. Avoid dropping any objects or inserting them into any openings or attachments of the product.
5. Do not use the product outdoors or in environments where aerosol (spray) products are being used or oxygen is being administered.
6. While the product is in operation, avoid placing it on sensitive surfaces to prevent any damage.
7. Do not use the product with a voltage converter or an extension cable.
8. The product should only be used for styling your hair and should not be used for any other purpose.
9. If the product is not functioning properly, has a damaged cord or plug, has experienced a sharp impact, has been dropped, damaged, left outdoors, or submerged in water, do not use it. Contact customer services for further guidance.
10. Avoid handling the plug or product with wet hands to prevent an electric shock.
11. Do not attempt to disassemble the product, as improper reassembly can lead to electric shock or fire hazards.
12. The product should not be used on synthetic hair.
13. This product is intended for indoor use only.
14. Never use it on someone who is sleeping.
15. Never drop or insert any object into any opening.

**CAUTION:** In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this product must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility company, or plugged into any socket where the electrical supply is unstable or likely to be turned off. When the product is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the product is switched off. For additional protection when the product is used in a bathroom, it is recommended that a Residual Current Device (RCD), with a residual operating current not exceeding 30 mA is installed in the electrical circuit supplying the bathroom. Contact a qualified electrical installer for advice.

Do not use any lubricants, cleaning agents, polishes or air fresheners on any part of the product.

## STORAGE

- Allow the brush to cool, then simply store out of reach of children in a safe, dry location.
- Do not jerk or strain the cord at plug connections.
- Do not wrap the power cable around the product.
- Allow the cord to hang or lie loose and straight at the point of entry into the product.

## CLEANING

- Use a soft dry cloth to clean.
- Always unplug and allow to cool prior to cleaning.
- Never use the following chemicals to clean the product: thinner, gasoline alcohols, or any other flammable chemicals.

## IMPORTANT INSTRUCTIONS

BEFORE USING THIS PRODUCT, PLEASE READ THE INSTRUCTIONS AND CAUTIONARY MARKINGS IN THIS MANUAL AND ON THE PRODUCT AND RETAIN FOR REFERENCE.

When using electrical products, especially when children are present, basic safety precautions should always be followed, including the following:

**WARNING: KEEP AWAY FROM WATER**

As with most electrical products, electrical parts are electrically live even when the switch is off.

1. Do not use this product near bathtubs, showers, basins, or other vessels containing water.
2. Do not use the product with wet hands.
3. Do not place or store the product near water.
4. Do not immerse or put under running water, even for cleaning purposes.
5. Do not place in or drop into water or other liquid.
6. Do not reach for the product if it falls into water.
7. Do not leave product in reach of children.

The product can be used by children aged from 8 years and above and persons with reduced physical, sensory or reasoning capabilities, or lack of experience and knowledge, only if they have been given supervision or instruction by a responsible person concerning the use of the product in a safe way and understand the hazards involved.

Cleaning and user maintenance shall not be made by children without supervision.

Do not allow the product to be used as a toy. Close attention is necessary when used by or near children. Children should be supervised to ensure that they do not play with the product.

This product has a non-self-resetting thermal cut out safety device to prevent overheating. If the product cuts out, unplug it from the mains supply socket and leave it to cool.

# CABLE SAFETY

These guidelines prioritise safety and proper handling of the power cable, aiming to prevent accidents and maintain the cable's functionality.

1. Check for damage: Before using the power cable, carefully inspect it for any signs of damage. If you notice any damage, do not use the cable.
2. Professional repair: If the supply cable is damaged, it should be replaced or repaired by the manufacturer, their service agent, or someone qualified to handle such repairs. This is important to prevent any potential hazards.
3. Avoid strain: Do not stretch the power cable or subject it to any strain. It should be kept free from any tension or pressure that could lead to damage.
4. Keep away from heat: Ensure that the power cable is not in close proximity to heated surfaces. Heat can potentially damage the cable, so it's important to maintain a safe distance.
5. Proper storage: When not in use, avoid wrapping the cable around the product or any other device. Improper coiling can cause damage to the cable and affect its functionality. Fold the cable together neatly and secure with the velcro fastening.
6. Safe unplugging: When unplugging the cable from the mains supply, avoid pulling on the cable itself. Instead, firmly grasp the plug and disconnect it safely. Pulling on the cable can lead to damage or electrical hazards.
7. Regular inspections: It is recommended to inspect the cable before each use. This will help identify any potential damage or issues that may have occurred since the last inspection, ensuring safety during operation.

# RECYCLING

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead, it should be handed to an appropriate collection point for the recycling of electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.